

PCP-35 capacitor charging module

User manual



Warning! This equipment might be dangerous. Please read user manual before starting operations.

Important note. Module is sensitive to the reverse polarity applied to the output. If you aren't sure in your application, please contact the factory for the details.



Overview / Description

PCP-35 capacitor charging module is a high-frequency switch-mode converter, which transforms AC input to regulated high voltage DC output to charge capacitors.

Output power is over 3500W for modifications with partial discharge (PD) and over 3000J/s for modifications with complete discharge (CD). Output voltage is customer defined in range up to 1500V (4000V on request).

Module is "industrial grade" and cannot be used for medical applications without modifications.

Cooling

Module is cooled with embedded fan. No external cooling is required.

Appearance



Connectors / Pins / Interface signals

INPUT:

Blue wires (2pcs) – 230VAC 50/60Hz input

HV OUTPUT:

Red wire – HV OUTPUT positive Black wire – HV OUTPUT negative

GROUND: M4 thread

Module should be grounded using this thread. It should be done before connecting module to the mains.

Warning! GROUND thread depth is 6mm only. Please use screws of the appropriate length

Grounding policy

HV OUTPUT negative and INTERFACE return are internally connected to the chassis ground. Other grounding policies are available on request


INTERFACE: PLD-20

19	17	15	13	11	9	7	5	3	1
20	18	16	14	12	10	8	6	4	2

PIN (color)	DESIGNATION	DESCRIPTION		
		Module's internal temperature test point.		
1 (-)	TEMP Test point	Standardly is dysfunctional; but can be		
		supplied on request.		
2,4,5,6 (black)		PINS 2,4,5,6 are connected to the circuit		
	Ground	ground of all internal circuits. The return signal connection for all interface signals		
		should be made to one of these pins.		
		A positive DC voltage applied to this pin		
3 (yellow)	Voltage Program	controls the output voltage set point.		
		1 5 1		
		$0-10V$ corresponds to $0-V_{MAX}$		
		The high voltage output is inhibited or		
	INHIBIT	enabled by this pin		
7 (blue)				
		0V – enabled; 5V or free-standing –		
		inhibited		
		This pin is pulled to the ground, when the		
8 (green)	Ready Indicator	output voltage is equal to the program		
		voltage (or higher than the program voltage)		
		These pins provide +15V DC that may be		
		used for status LEDs etc.		
9, 10 (red)	+15 V			
		Maximum output current 50mA		
		This pin provides +5V DC that may be		
11 (orange)	+5 V	used for status LEDs etc.		
11 (orange)	13 4			
10 10	N/O	Maximum output current 50mA		
12, 18	N/C	This pin is pulled to the ground in the		
13 (white; black	Over TEMP	case of module's overheating		
mark)	OVEL TENII	(approx 72°C)		
447 11	0 17 1/	This pin is pulled to the ground when		
14 (white; blue	Over Voltage	overvoltage occurs. The high voltage		
mark)	Status	output is also disabled when this occurs		
		PIN15 is pulled to ground when the		
15 (green / yellow)	End of Charge	output voltage below the program		
13 (green / yenow)	Indicator	voltage.		
		Elsewise PIN15 is pulled to +15V.		
		The HV OUTPUT is inhibited (when		
		+15V are applied) or enabled (when 0V		
16 (blue / white)	Secondary Inhibit	are applied or the pin is free standing).		
16 (blue / white)	Secondary Innibit	This pin should be used only to control		
		parallel operations of two or more power		
	4	modules.		
		The voltage at this is a buffered signal		
4 7 7 7 0	77.14	proportional to the instantaneous output.		
17 (violet)	Voltage Monitor	0.1077		
		0-10V corresponds to 0-V _{MAX}		
	İ	Current capability 1,5mA; R _{out} = 1kOhm		

		This pin is pulled to ground when some failure occurs. The high voltage output is disabled when this occurs		
19 (white; red mark)	Fault Indicator *	Failures: output short-circuit overtemperature overvoltage output open circuit charge timeout		
20 (transparent)	HV ON Indicator	This pin is pulled to the ground, when module provides the power to the load		

* see also Faults section



Operations

- 1. *Inhibit* the high voltage output (*PIN7* of *INTERFACE*)
- 2. Set the desired output voltage by applying a DC voltage to the *Voltage Program (PIN3* of *INTERFACE*)
- 3. Apply power to the module
- 4. *Enable* the high voltage output (*PIN7* of *INTERFACE*)
- 5. Operate, then *Disable* the high voltage output, then disconnect module from the mains

Faults section

Module sets *Fault* state in the following cases:

- *overheating* (temperature of the module exceeds approx. 72 °C level)
- overvoltage (voltage on the load exceeds 110% of V_{MAX} level)
- *short-circuit* at module's output (triggering threshold is about 0.8-1.0s)
- open-circuit at module's output
- *charging timeout* (value by default is about 5s, other timeouts can be set by request)

For most of faults once the *Fault* has occurred one should eliminate the Fault cause, afterthen "reboot" the module (this means to *DISABLE* module and *ENABLE* it again).

Exceptions:


- for *open-circuit* failure one should remove the power from the module and apply it again
- for *overheating* failure module may start its operations again if the temperature decreases rapidly (i.e. faster than in 5-10s) down to approx. 65 °C level

ELECTRICAL

230 VAC, 50/60 Hz		
user selectable in 300-1500V range		
(up to 4000V on special request)		
>3500W (can be achieved in regime		
70-100% V _{MAX} , 230VAC input, 25		
°C, partial discharge modifications)		
>3000J/s (can be achieved in		
regime 0-100% V _{MAX} , 230VAC		
input, 25 °C, complete discharge		
modifications)		
0.5% of V_{MAX}		
0.5% of V_{MAX}		
More than 85%		
~ 0.90		
from open circuit		
from short circuit		
from over-temperature		
from over-voltage		
shut down on charging timeout		
Forced air (build in fan)		
+10 +40 °C		
-20 +60 °C		
90%, non-condensing		

MECHANICAL

Dimensions	see dimensional drawing below
Weight	approx 2.8 kg



How to order?

PCP-35-XXXX-YY, where

XXXX means V_{MAX} voltage (user selectable in 300V-1500V range, up to 4000V on special request)

YY means either CD (complete discharge modification) or PD (partial discharge modification); if YY is missed PD modification will be supplied

Examples (the most popular modifications):

1 \ 1 1	1
PCP-35-300V-PD	300V, partial discharge
PCP-35-500V-PD	500V, partial discharge
PCP-35-700V-PD	700V, partial discharge
PCP-35-1000V-PD	1000V, partial discharge
PCP-35-1000V-CD	1000V, complete discharge
PCP-35-1500V-CD	1500V, complete discharge

Other modifications are available on request.